

Standard Departure Routes - Instrument (SID) Pavlodar RWY 21

DOSAK 3H

After take-off climb straight ahead to 1000 FT or above. At 5.5 NM PVL, turn LEFT on track 057° until intercept R097°PVL, then proceed on track 097° to DOSAK (R096.7° D42.7NM PVL).

PIVAL 3H

After take-off climb straight ahead to 1000 FT or above. At 5.5 NM PVL, turn LEFT on track 085° until intercept R125°PVL, then proceed on track 125° to PIVAL (R124.5° D38.7NM PVL).

KEKAM 3H

After take-off climb straight ahead to 1000 FT or above. At 5.5 NM PVL, turn LEFT on track 124° until intercept R164°PVL, then proceed on track 164° to KEKAM (R164.0° D50.0NM PVL).

GOBSO 3H

After take-off climb straight ahead to 1000 FT or above. At 5.5 NM PVL, turn LEFT on track 155° until intercept R185°PVL, then proceed on track 185° to GOBSO (R185.0° D79.5NM PVL).

ROHIL 1H

After take-off climb straight ahead to 2500 FT or above. At 13.0 NM PVL proceed on track 216° to ROHIL (R215.6° D78.0NM PVL).

ABELI 3H

After take-off climb straight ahead to 2500 FT or above. At 13.0 NM PVL, turn RIGHT on track 264° until intercept R234°PVL, then proceed on track 234° to ABELI (R233.6° D79.0NM PVL).

ADODA 3H

After take-off climb straight ahead to 2500 FT or above. At 13.0 NM PVL, turn RIGHT on track 317° until intercept R277°PVL, then proceed on track 277° to ADODA (R277.0° D76.1NM PVL).

ADASA 3H

After take-off climb straight ahead to 2500 FT or above. At 13.0 NM PVL, turn RIGHT on track 328° until intercept R288°PVL, then proceed on track 288° to ADASA (R288.2° D75.8NM PVL).

BAGNU 3H

After take-off climb straight ahead to 2500 FT or above. At 13.0 NM PVL, turn RIGHT on track 353° until intercept R313°PVL, then proceed on track 313° to BAGNU (R312.6° D70.4NM PVL).