

STANDARD DEPARTURE ROUTES - INSTRUMENT (SID) SEMEY RWY 26
OBUNA 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn RIGHT on track 347° until intercept R307° SEM, then proceed on track 307° to OBUNA (R306.6° D49.7NM SEM).
ELSUT 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn RIGHT on track 058° until intercept R018° SEM, then proceed on track 018° to ELSUT (R018.3° D58.7NM SEM).
ADARO 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn RIGHT on track 099° until intercept R059° SEM, then proceed on track 059° to ADARO (R059.3° D67.8NM SEM).
LIRNA 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn LEFT on track 054° until intercept R094° SEM, then proceed on track 094° to LIRNA (R094.0° D44.2NM SEM).
LUNOV 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn LEFT on track 130° until intercept R170° SEM, then proceed on track 170° to LUNOV (R169.7° D43.1NM SEM).
UVTOK 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn LEFT on track 157° until intercept R197° SEM, then proceed on track 197° to UVTOK (R197.2° D45.7NM SEM).
ADLAN 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn LEFT on track 180° until intercept R220° SEM, then proceed on track 220° to ADLAN (R220.2° D43.4NM SEM).
LUREL 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM proceed on track 257° to LUREL (R256.7° D42.9NM SEM).
ETORI 1F After take-off climb straight ahead to 1500 FT or above. At 5.0NM SEM turn RIGHT on track 308° until intercept R278° SEM, then proceed on track 278° to ETORI (R277.9° D43.6NM SEM).