

Standard Departure Routes - Instrument (SID) Kostanay RWY 32

NELTI 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn RIGHT on track 037° until intercept R007°KST, then proceed on track 007° to NELTI (R007.5° D73.1NM KST).
Cross NELTI at FL150 – FL200.

AKOSO 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn RIGHT on track 089° until intercept R049°KST, then proceed on track 049° to AKOSO (R048.8° D64.9NM KST).
Cross AKOSO at FL120 – FL200.

BIMSO 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn RIGHT on track 112° until intercept R072°KST, then proceed on track 072° to BIMSO (R072.0° D64.4NM KST).
Cross BIMSO at FL120 – FL200.

DOKUT 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn RIGHT on track 138° until intercept R098°KST, then proceed on track 098° to DOKUT (R097.9° D63.9NM KST).
Cross DOKUT at FL120 – FL200.

ARDIK 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 099° until intercept R140°KST, then proceed on track 140° to ARDIK (R139.6° D63.5NM KST).
Cross ARDIK at FL120 – FL200.

BALOK 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 114° until intercept R154°KST, then proceed on track 154° to BALOK (R154.2° D58.5NM KST).
Cross BALOK at FL120 – FL200.

BUDER 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 135° until intercept R175°KST, then proceed on track 175° to BUDER (R175.3° D58.6NM KST).
Cross BUDER at FL120 – FL200.

DOPAN 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 150° until intercept R190°KST, then proceed on track 190° to DOPAN (R190.0° D63.8NM KST).
Cross DOPAN at FL120 – FL200.

BAMIK 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 184° until intercept R224°KST, then proceed on track 224° to BAMIK (R224.2° D64.5NM KST).
Cross BAMIK at FL120 – FL200.

TITUR 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 237° until intercept R267°KST, then proceed on track 267° to TITUR (R266.9° D87.6NM KST).
Cross TITUR at FL120 – FL200.

LANOR 3F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn LEFT on track 317° to LANOR (R317.7° D63.0NM KST).
Cross LANOR at FL120 – FL200.

UNIBE 2F

After take-off climb straight ahead to 1300FT or above. At 5.7NM KST, turn RIGHT on track 169° until intercept R129°KST, then proceed on track 129° to UNIBE (R129.3° D60.5NM KST).
Cross at FL120 – FL200.