

Standard Departure Routes - Instrument (SID) Kostanay RWY 14

NELTI 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 328° until intercept R007°KST, then proceed on track 007° to NELTI (R007.5° D73.1NM KST).
Cross NELTI at FL150 – FL200.

AKOSO 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 009° until intercept R049°KST, then proceed on track 049° to AKOSO (R048.8° D64.9NM KST).
Cross AKOSO at FL120 – FL200.

BIMSO 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 032° until intercept R072°KST, then proceed on track 072° to BIMSO (R072.0° D64.4NM KST).
Cross BIMSO at FL120 – FL200.

DOKUT 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 068° until intercept R098°KST, then proceed on track 098° to DOKUT (R097.9° D63.9NM KST).
Cross DOKUT at FL120 – FL200.

ARDIK 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 139° to ARDIK (R139.6° D63.5NM KST).
Cross ARDIK at FL120 – FL200.

BALOK 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 155° to BALOK (R154.2° D58.5NM KST).
Cross BALOK at FL120 – FL200.

BUDER 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 205° until intercept R175°KST, then proceed on track 175° to BUDER (R175.3° D58.6NM KST).
Cross BUDER at FL120 – FL200.

DOPAN 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 220° until intercept R190°KST, then proceed on track 190° to DOPAN (R190.0° D63.8NM KST).
Cross DOPAN at FL120 – FL200.

BAMIK 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 264° until intercept R224°KST, then proceed on track 224° to BAMIK (R224.2° D64.5NM KST).
Cross BAMIK at FL120 – FL200.

TITUR 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 307° until intercept R267°KST, then proceed on track 267° to TITUR (R266.9° D87.6NM KST).
Cross TITUR at FL120 – FL200.

LANOR 3E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn RIGHT on track 358° until intercept R318°KST, then proceed on track 318° to LANOR (R317.7° D63.0NM KST).
Cross LANOR at FL120 – FL200.

UNIBE 2E

After take-off climb straight ahead to 1300FT or above. At 3.2NM KST, turn LEFT on track 128° to UNIBE (R129.3° D60.5NM KST).
Cross UNIBE at FL120 – FL200.